



Humidity, Temperature & Dew Point Transmitter **H5 LINE**

User manual
21/04 - Code: ISTR_M_H5_E_02_--



Copyright © 2007/2021, Ascon Tecnologic Srl

All rights reserved

No part of this document may be stored in a retrieval system, or transmitted in any form, electronic or mechanical, without prior written permission of Ascon Tecnologic Srl.

Ascon has used the best care and effort in preparing this manual and believes that the information contained in this publication is accurate.

As Ascon Tecnologic continues to improve and develop products, the information contained in this manual may also be subject to change. Ascon Tecnologic reserves the right to change such information without notice.

Ascon Tecnologic makes no warranty of any kind, expressed or implied, with regard to the documentation contained in this manual. Ascon Tecnologic shall not be liable in any event - technical and publishing error or omissions - for any incidental and consequential damages, in connection with, or arising out of the use of this manual.

sigmadue®, gammadue® e deltadue® sono marchi registrati Ascon Tecnologic Srl.

All other trade names or product names are trademarks or registered trademarks.

Ascon Tecnologic srl

Headquarters: viale Indipendenza 56, 27029 Vigevano (PV)

Tel.: +39 0381 69871

Fax: +39 0381 698730

Internet site: www.ascontecnologic.com

E-mail: info@ascontecnologic.com

INDEX

Chapter 1

Getting started	1
1-1 Product description	1
1-2 Order Code	2
1-3 Hardware configuration (1 st part of the Order Code)	2
1-3-1 Mounting type (fields A and B of the Order Code)	2
1-3-2 Probe sheath material.....	3
1-3-3 Sensor protection filter (field D of the Order Code)	3
1-4 Output configuration (2 nd part of the Order Code)	3
1-5 Accessories configuration (3 rd part of the Order Code)	4
1-6 Transmitter configuration.....	4
1-6-1 Basic configuration	4
1-6-2 Advanced configuration	4
1-7 Usage	4

Chapter 2

Start up.....	5
2-1 Installation	5
2-2 Installation Precautions	5
2-3 Dimensions.....	5
2-3-1 Transmitter	5
2-4 Electrical connections.....	7
2-4-1 Version with internal removable spring terminals and M16 conduits	7

Chapter 3

Basic Functions.....	9
3-1 Transmitter functions	9
3-1-1 Data acquired from the Humi-Chip	9
3-1-2 Data calculated by the instrument	9

Chapter 4

Maintenance.....	11
4-1 Cleaning/replacing the dust filter	11
4-2 Replacement of the Humi-Chip module.....	12

Chapter 5

Advanced functions	13
5-1 Analogue Outputs	13
5-2 Serial Port Setting	13
5-3 Alarms	14
5-3-1 Alarm acknowledge	14
5-3-2 Start-Up Disabling (Blocking)	14
5-3-3 Alarm Source	15
5-3-4 Relay output alarm destination	15
5-3-5 Alarm types	15
5-4 Relay Output	16
5-5 Real Time Clock (RTC) and Associated Functions	16
5-5-1 Date and time	16
5-5-2 Tracing Events (DATA EVENT) and Data Logging (DATA LOGGER)	17
5-6 Commands	18
5-7 Calibration commands	18
5-7-1 Humi-Chip sensor calibration	19
5-7-2 Sensor replacement	20

Chapter 6

The Modbus Protocol	21
6-1 Communication Lines	21
6-2 Modbus Functions	21
6-3 Common Registers and Diagnostics	22
6-3-1 MODBUS Exception Responses	22
6-3-2 Status register	22
6-3-3 Diagnostics	23
6-4 Discrete data (input and coils)	23
6-5 Data registers	23
6-5-1 Variables and Parameters	23
6-5-2 Identity Registers	25
6-5-3 Command registers	25
6-5-4 Retentive registers	25
6-5-5 Configuration registers	27
6-5-6 Diagnostic Registers	28
6-5-7 DATA EVENT and DATA LOGGER registers	28

Chapter 7

Commands	29
7-1 Program commands	29
7-1-1 Cmd_Res	29
7-1-2 Cmd_Ack	29
7-1-3 Cmd_tst	29
7-1-4 Cmd_calsens	29
7-1-5 Cmd_cnsgsens	29
7-2 System Commands	30
7-2-1 Calibration Commands	30
7-2-2 Operating System Commands	30
7-2-3 Cmd_memo_eventlog	30

Chapter 8

Configuration	31
8-1 Registers.....	31
8-1-1 Modbus Register Setting	31
8-1-2 Baud Rate Setting.....	32
8-1-3 Temperature Engineering Units	32
8-1-4 Decimal digits	32
8-1-5 Analogue Output Type	33
8-1-6 Input Source for Analogue Outputs.....	33
8-1-7 Alarm Type Setting.....	34
8-1-8 Alarm Reset Type Setting	34
8-1-9 Alarm Source Setting.....	35
8-1-10 Alarm Output Setting	35
8-1-11 Register of analogue outputs value on sensor error.....	35
8-1-12 EVENT Logging Registers.....	36
8-1-13 Humidity and Temperture Offset Registers.....	36
8-1-14 Reset Register	36

Chapter 9

Configuration Tools	37
9-1 System requirements	37
9-2 Installing and executing the configuration software	37
9-2-1 Installing the program	37
9-3 File menu and Parameter setting.....	38
9-3-1 Saving the transmitter data	38
9-3-2 To save the transmitter settings in a file.....	38
9-3-3 Parameters setting.....	39
9-3-4 To send the parameters setting into the trasmitter (Download configuration)	39
9-3-5 To store the configuration as a file (Save).....	40
9-3-6 To recall a previously stored file.....	40
9-3-7 Setting the Options	41
9-3-8 Printing the configuration	41
9-4 Communications menu	42
9-4-1 Communications parameters setting	42
9-5 Trend Menu	43
9-6 Menu “Commands”	43
9-6-1 Min./Max. Reset	43
9-6-2 Alarm Ack	43
9-6-3 Store configuration on EEPROM	43
9-6-4 Device Reset.....	43
9-6-5 Restore Default configuration	44
9-7 Database	44
9-8 Sensor Calibration	45
9-8-1 “Humi-Chip” sensor calibration procedure	45

Chapter 10	
“Data event” and “Data logger”	49
10-1 Functioning mode	49
10-2 Data format	49
10-3 Accessing the stored data	50
Chapter 11	
Diagnostics	51
11-1 Analogue output calibration diagnostic values (diag_reg0).....	51
11-2 Analogue Output diagnostic (diag_reg2).....	51
11-3 Humi chip sensor calibration diagnostic values (diag_reg3)	52
Appendix A	
Modbus Address Map	53
A-1 Modbus Address Map.....	53
Appendix B	
Characteristics.....	57
B-1 Technical characteristics	57
Appendix C	
Troubleshooting.....	59
Appendix D	
Warranty	61
D-1 Warranty and repairs	61

Preface

In order to guarantee the safe use of your device, we recommend that you read this manual carefully. The following notes give you information on how to use this manual.

- User Requirements	vii
- Purpose of this manual	vii
- Using this manual	viii
- Getting started	viii
- Current documentation on Internet	ix
- We are interested in your comments	ix
- Legal statement	ix
- Validity of documentation	ix

User Requirements

The products described in this manual should be installed, operated and maintained only by qualified application programmers and software engineers, electricians or persons instructed by them, who are familiar with automation safety concepts and applicable national standards.

Ascon Tecnologic Srl assumes no liability for damage to any product resulting from the disregard of information contained in this manual.

Purpose of this manual

This manual contains the information necessary to understand and to configure the H5 line Humidity and Temperature transmitter.

This manual is written on the assumption that the reader possesses basic knowledge of Fieldbus techniques, in particular for Modbus. Use this manual if you are responsible for configuring and installing Ascon Tecnologic modules with Modbus interface.

Using this manual

Specifications within the text of this manual are given in the International System of Units (SI), with non SI equivalents in parentheses.

Fully capitalized words within the text indicate markings found on the equipment. Words in bold style within the text indicate markings found in the Configuration Tools. Warnings, Cautions and Notes are used to emphasize critical instructions.

NOTICE:

This product must be used by qualified operators and with appropriate procedures, exclusively for the purposes set out in this manual.

In this manual, the following symbols are used to indicate and classify the precautions to be taken. These precautions must be strictly observed, the relative non-observance can cause serious injuries to people and things.



DANGER!

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING!

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Caution

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or property damage.

Note: Highlights important information about an operating procedure or the equipment.
Per un uso agevole di questo manuale sono stati previsti i seguenti aiuti:

- A main table of contents covering all subject matter is provided at the front of this manual.
- A table of contents covering information within a section or an appendix is provided at the front of the individual section or appendix.
- Appendices covering specific topics are provided following the last section in the manual.
 - MODBUS Addresses Map;
 - Suggestions and examples;
 - Definitions, symbols and conversion tables.

Getting started

In the first section you are introduced to Ascon Tecnologic modules basics. The following sections contain general information that applies to all modules or module groups of the series. Topics are for example:

- Overview of the product;
- Terminal installation and wiring;
- Common technical data.

Related documents

For additional information regarding MODBUS in general, refer to the documents issued by the respective Users Organisations. If you need specific information on an Ascon Tecnologic, refer to the specific data sheet.

Current documentation on Internet

Make sure you are always working with the latest documentation published. The latest changes or additional information can be found on the Internet at:

<http://www.ascontecnologic.com>

Ascon Tecnologic Products pages are to be updated frequently. It is possible therefore that the Data Sheets published on the Internet would have a publishing date more recent than the date of this manual.

We are interested in your comments

Ascon Tecnologic srl makes any effort to improve the quality of its manuals. Nevertheless errors and omissions are always possible. If you have suggestions or indications about the content or the form of this manual, Ascon Tecnologic srl will greatly appreciate your comments. You can send an e-mail to:
`support@ascontecnologic.com`

Legal statement

This manual, including all illustrations contained herein, is copyright protected. Use of this manual by any third party in departure from the copyright provision is prohibited. Reproduction, translation, and electronic or photographic archiving or alteration requires the express written consent of Ascon Tecnologic srl. Ascon Tecnologic srl reserves the right to make any technical changes that serve the purpose of technical progress. External products are always named without reference to patent rights. The existence of such rights shall not be excluded.

Validity of documentation

This manual mainly contains the description of H5 line Humidity and Temperature transmitter that was available when this manual was published. Ascon Tecnologic srl reserves the right to make any technical extension and change to the equipment that would serve the purpose of technical progress. Up to the time that a new manual revision is published, any update or change will be documented on the Internet at:

`http://www.ascontecnologic.com`

Chapter 1

Getting started

1-1 Product description

The **H5** line transmitters are Humidity, Temperature & Dew Point electronic measuring instruments that determine measurements by means of a highly accurate, condensation resistant capacitive sensor integrated in a silicon microchip (the “**Humi-Chip**” module).

This technology provides accurate process measurements, reliability and excellent long-term stability. Accurate Dew Point calculation is obtained by the integrated humidity and temperature sensors.



Caution

The sensor must not be used in the presence of contaminating or aggressive chemicals.

The “Humi-chip” module that incorporates the sensor can be easily replaced without the need for re-calibration; its environmental limits are: 0... 100% for Relative Humidity (RH) and -30... +90°C for Temperature and Stability: <0.5 RH% per year for Long-term drift.

When purchasing, if the ordering code is correctly composed, the transmitter can be installed and used with no further settings.

Expert users using the “Controller Explorer” software can easily set the transmitter parameters. Through the serial port the user can connect the H5 to a Personal Computer and in this way configure:

- The analogue outputs;
- The alarms;
- The data logger;
- The event tracer.




WARNING!

In order to install and use the transmitter, follow the instructions in chapters 1... 4. The procedure to configure the transmitter parameters can be found at chapters 5... 9.

1-2 Order Code

Hardware options are added to H5 transmitters as required by the user. The options that are to be installed are specified by the first part of the Ordering Code.



Where:

Mounting	Dimensions	A	B
Wall	Ø20 x L110	P	0
Duct	Ø20 x L250	C	2
	Ø20 x L530	C	5
Remote	Ø20 x L160, cable 2 m	R	2
	Ø20 x L160, cable 5 m	R	5

Filter	D
Stainless steel wire mesh	R
Sintered stainless steel	S
Teflon	T

1st Analogue output - Humidity [1] - [3]	E
Not fitted	0
4... 20 mA/0... 100% UR	1
0... 10 V/0... 100% UR	2
0... 1 V/0... 100% UR	3

2 nd Analogue output - Temperature [3]		F
Not fitted		0
Temperature (T)	4... 20 mA	1
	0... 10 V	2
	0... 1 V	3
	PT100 - IEC751 compliant [4]	P
Dew Point (DP)	4... 20 mA	4
	0... 10 V	5
	0... 1 V	6
ΔT (T - DP)	4... 20 mA	7
	0... 10 V	8
	0... 1 V	9

Temperature range [2] (°F on request)	G
(if F = 0 or F = P)	0
-30... +70°C	1
-20... +30°C	2
0... 50°C	3
0... 100°C	4

Serial Communications + Special Functions	I
Not fitted	0
RS485 Modbus + Alarms + Events + Data logging	5

Example: H5-R50R-141-M050

- Notes:**
1. On request, the 1st analogue output can be used for T, DP or ΔT.
 2. Suggested temperature ranges:
DP: -30... +70°C or 0... 100°C
ΔT: 0... 50°C.
 3. Other measure ranges available (selectable using the serial communications).

1-3 Hardware configuration (1st part of the Order Code)

1-3-1 Mounting type (fields A and B of the Order Code)

The H5 line can be installed in different modes also through dedicated accessories:

- Wall installation, mounting the transmitter directly;
- Sensor remote installation (cable of 2 or 5 m long) also with the wall mounting bracket for remote sensor (Order Code: **AH-SMP01**);

- Sensor remote installation (cable of 2 or 5 m long) also with the wall mounting bracket for remote sensor (Order Code: **AH-FLA20**).

Mounting	Dimensions	A	B
Wall	Ø20 x L110	P	0
Duct	Ø20 x L250	C	2
	Ø20 x L530	C	5
Remote	Ø20 x L160, cable 2 m	R	2
	Ø20 x L160, cable 5 m	R	5
	Ø20 x L160, cable 10 m	R	1

1-3-2 Probe sheath material

The probe for duct mounting is made in polycarbonate that can be used in the food and beverage industries.

1-3-3 Sensor protection filter (field D of the Order Code)

Environmental protection for the Humi-chip module is provided by one of three user selected filter types:

- Wire mesh stainless steel filter with threaded filter protection.
Porosity of 25 µm and response time of 5 s (0... 63%) make it suitable for clean environments dust and moderate wind conditions.
- Stainless steel sintered filter with threaded connection.
Porosity of 5 µm and response time of 10 s (0... 63%) make it suitable for dusty environments, not moisture resistant.
- Teflon filter with threaded connection.
Porosity of 1 µm and response time of 120 s (0... 90%) make it suitable for aggressive chemical environments, not suitable with highgrade humidity.

Filter	D
Stainless steel wire mesh	R
Sintered stainless steel	S
Teflon	T

1-4 Output configuration (2nd part of the Order Code)

Using the order code, the user can order the configuration of the output ports necessary to the application:

- Number of analogue outputs (0, 1 or 2);
- Output type (Current/Voltage output, Relative Humidity, Temperature, Dew Point and ΔT);
- Temperature output range;
- If the analogue output configuration cannot be specified in the Ordering Code, the user may configure the outputs with the Controller Explorer software (see "Chapter 5 - **Advanced functions**" for details).

1 st Analogue output - Humidity [1] - [3]	E
Not fitted	0
4... 20 mA/0... 100% UR	1
0... 10 V/0... 100% UR	2
0... 1 V/0... 100% UR	3

2 nd Analogue output - Temperature [3]		F
Not fitted		0
Temperature (T)	4... 20 mA	1
	0... 10 V	2
	0... 1 V	3
	PT100 - IEC751 compliant	P
Dew point (DP)	4... 20 mA	4
	0... 10 V	5
	0... 1 V	6
ΔT - Temperature difference (T - DP)	4... 20 mA	7
	0... 10 V	8
	0... 1 V	9

1-5 Accessories configuration (3rd part of the Order Code)

The transmitter allows the installation of some optional accessories in order to guarantee good application flexibility. The available options are the RS485 communications port with the Real Time Clock (RTC) to activate special functions such as: alarm events and data logger.

Serial Communications + Special Functions	I
Not fitted	0
RS485 Modbus + Alarms + Events + Data logging	5

1-6 Transmitter configuration

1-6-1 Basic configuration

If all hardware configurations and options can be specified in the Ordering Code, the transmitter can be installed and used immediately.

1-6-2 Advanced configuration

If all hardware configurations and options are not specified in the Ordering Code, the transmitter can be configured with the Humidity Explorer software.

1-7 Usage

The main function of the instrument is to read the environmental conditions from the Humi-Chip sensor: Relative Humidity (RH), Temperature (T), Dew Point (DP) and Temperature difference (ΔT) between the temperature and the Dew Point Temperature ($\Delta T = T - DP$). After the values are converted they can be retransmitted through the analogue outputs and can be used to configure the alarms. The measures together with the min./max. values are always available as Modbus variables. The limit values can be reset through the serial line and the Modbus protocol.

No buttons are available on the transmitter. The only operator interface is through the Modbus protocol.

When the analogue outputs are installed in the instrument, each can be configured to retransmit the value of one of the 4 variables RH, T, DP or ΔT . During the configuration phase the user can also select the transmission mode (current/voltage).

2-1 Installation

Consult the installation manual for further details.

2-2 Installation Precautions


Humi-Chip measurement module incorporates an integrated temperature sensor. The measured values are correct when the Humi-Chip Humidity and Temperature are both in equilibrium with the surrounding ambient conditions.

For optimum performance, the following recommendations must be observed:


1. Install the sensor in the most representative location of the ambient to be controlled;
2. Avoid the following conditions:
 - Direct exposure to sun and atmospheric agents;
 - Installing the sensor next to heaters, coolers, steam vents and humidifiers;
 - Turbulences which can generate unstable pressures.

2-3 Dimensions

2-3-1 Transmitter




Remote sensor
mounting



Outputs **Output M16 Conduit**




Mounting
holes




Mounting for **Adjustable flange Ø100 self locking (AH-FLA20 optional)**

Duct model
H5-C...




Wall mounting **Bracket for remote sensor (AH-SMP01 optional)**
bracket for
remote sensor




2-4 Electrical connections

2-4-1 Version with internal removable spring terminals and M16 conduits






- Notes:**
1. Two M16 conduit for output cables up to Ø8.5 mm.
 2. Spring terminal strip for cable sections of 0.14... 1.5mm² (AWG28... AWG16).
 3. The AO1 output is isolated from the optional AO2 output.

Analogue AO1 and AO2 set as current outputs output terminals (0/4... 20 mA)




AO1 and AO2 set as voltage outputs (0... 1, 0... 5, 0...10Vdc)



Note: When the RS485 communications port is not present in the transmitter on the same terminals are present the signals of the embedded RS232 communications port. (see "Chapter 8 - Configuration").

PT100 output terminals



Chapter 3

Basic Functions

3-1 Transmitter functions

The H5 line transmitters receive humidity/temperature data from an external sensor and convert them in order to retransmit analogue signals or display decimal values.

The basic functions of the H5 instruments include also some calculations in order to obtain new values from the data acquired.

3-1-1 Data acquired from the Humi-Chip

Humidity and Temperature data are received from the Humi-Chip in digital format; once data are in the transmitter, they are linearized and converted. Using Relative Humidity (RH) and Temperature (T) measurements the instrument calculates the Dew Point (DP) and the Temperature - Dew Point temperature difference (ΔT).

The measurement is made once every second continuously.

The variable values, stored and displayed, have 1 decimal digit.

The Relative Humidity (0... 100%) acquired by the sensor is composed by a 12 bit value. The Temperature (-40... +123.8°C) is composed by a 14 bit value. Both these values are processed in order to compensate the non linearity of the reply.

Relative Humidity (RH) The Relative Humidity value acquired from the Humi-Chip sensor is modified by a 2nd order polynomial calculation in order to obtain a non-linearity error of $\pm 0.1\%$ RH.

Temperature (T) The Temperature measurement is made using a BANDGAP sensor type that is inserted in the same body of the Humidity sensor and with which it shares the electronic interface. The measurement is corrected in order to delete non linearity errors normally present near to the range limits.

3-1-2 Data calculated by the instrument


Dew Point and ΔT The Dew Point value is calculated starting from the final RH and T values, while ΔT (difference between the Temperature and the Dew Point Temperature) is calculated making the algebraic difference between the 2 values:

$$\Delta T = T - DP.$$

Chapter 4

Maintenance

4-1 Cleaning/replacing the dust filter



The dust filter should be cleaned from time to time depending on the working conditions. Cleaning is done by:

1. Removing the filter from the probe as described in the “*Replacing the Humi-Chip module*” paragraph ((points 1, 2 and 3);
2. Clean the wire mesh filter by washing it with water. The Teflon and the Sintered stainless steel filters should be cleaned with compressed air (the air pressure must be applied within the filter). Make sure to perform the cleaning far from the Humi-Chip module so as not to cause damage.

If this is not sufficient, the filter should be replaced.

4-2 Replacement of the Humi-Chip module


The sensor of the “Humi-Chip” module does not need any periodic calibration. The replacement sensor is delivered factory calibrated.

Calibration is not required after replacement. If the replacement of the “Humi-Chip” module is necessary, proceed as follows:

1. Switch off the power supply;
2. Verify that the “Humi-Chip” module is at a safe temperature;
3. Unscrew (A) the filter (or the plastic protection), then (B) slide it away from the sensor;




4. When present, (C) separate the stainless steel wire mesh filter from the Humi-Chip module then (D) gently withdraw the sensor module in order to separate the Humi-Chip from the mounting connector. The Humi-Chip module must be gripped from the body (D') and not from the ventilated part of the sensor (D'');




5. Insert the new module aligning the insertion key present in the Humi-Chip connector to the groove of the correspondent 8 pin connector; gently push the new module in position. Humi-Chip module must be gripped from the body (D') and not from the ventilated part of the sensor (D'');

**Connettore sul modulo
Humi-Chip (maschio)**



**Connettore sullo stelo del
trasmettitore (femmina)**



6. When present, re-install the wire mesh filter and its plastic protection, or re-install the filter.

Chapter 5

Advanced functions



Caution

This chapter and those that follow are devoted to advanced users only. An not-correct transmitter configuration may cause a malfunction.

Expert users can modify the configuration of the H5 transmitter in order to adjust the transmitter features to the project specification. Using the 485 serial communications port and the Modbus protocol the user can change:

- Type and range of the analogue outputs;
- Serial port settings and Modbus address;
- Alarm parameters (reset, start-up disabling, source, destination and type);
- Relay output setting;
- The setup of the Events (EVENT) and Data logging (LOGGER) (when the RTC option is installed);
- Download EVENT/LOGGER data.

5-1 Analogue Outputs

The 2 analogue outputs are optional and programmable, they can function as Current/Voltage retransmission outputs.

Output type	Signal type
Current Output (mA)	0... 20 mA
	4... 20 mA
Voltage Output (V)	0... 1 V
	0... 5 V
	0... 10 V

Each output can be connected to one of the 4 measured/calculated variables (**RH**, **T**, **DP** and ΔT). The range of the output is the same of the variable range. It is possible, for each analogue output, to define the range of the connected variable (start and end of range).

5-2 Serial Port Setting

Using the serial communications port the user can set also the RS485 communications parameters:

- Node address;
- Protocol;
- Baudrate.

5-3 Alarms

The transmitter has 5 alarms that can be freely and independently addressed to the relay alarm output. When more than one alarm is simultaneously active on the relay output, the relay status is determined by the **AND/OR** logical status of the alarms. First are evaluated the inputs that are connected in **AND** then those connected in **OR**. When in alarm mode, the output relay can be set to be activated (contact closed - NA configuration) or released (contact open - NC configuration). The input of each alarm can be combined with any of the system measurements: **Humidity, Temperature, DP, T, ΔT and Humi-chip break**.

Each alarm can be configured as **minimum** or **maximum**, **absolute**, **deviation** or **band threshold**, **instantaneous** or **delayed**, **inhibit at activation** (Blocking) or **acknowledge** (Latching). Each alarm can also be configured for **signal source**, **type of alarm**, **reset method**, **power up activation mode** and **destination**. The alarm status is always available in STATUS REGISTER.

Note: The alarm parameter format is referred to the input range associated to the alarm.

5-3-1 Alarm acknowledge

There are 2 different reset modes:

Name	Description
Auto	The alarm is activated when an alarm condition is detected, the alarm status is removed as soon as the alarm condition is removed.
Latching	The alarm is activated when an alarm condition is detected, the alarm status is removed only when the alarm has been acknowledged and the alarm condition has been removed (note)

Note: The alarm acknowledge can be done only through serial communications commands. The tables with the alarm status related to the acknowledge type follows:

AUTO

Status	Status transitions				Indication	Relay output
	Input variable		Acknowledge			
	Normal condition	Alarm condition	Acknolegdge not done	Done (ACK)		
Normal	No status changes	Alarm			OFF	Not active
Alarm	Normal	No status changes			ON	Active

Latching

Status	Status transitions				Indication	Relay output
	Input variable		Acknowledge			
	Normal condition	Alarm condition	Not done	Done (ACK)		
Alarm			No status changes	ACK	ON	Active
Acknowledge	Normal	No status changes			ON	Active

5-3-2 Start-Up Disabling (Blocking)

At Power ON each alarm can be programmed to function in normal mode or in blocking mode. When in normal mode, the alarm will be active or not depending on the input status also at Power ON; when in blocking mode, the first alarm activation is always inhibited; the alarm activation is postponed to the reset mode set.

Start-Up Disabling (Blocking)

Name	Description
Normal	The alarm is never inhibited
Blocking	The first alarm condition after Power ON is discarded

5-3-3 Alarm Source

There are 5 different sources that can activate the alarms:

Name	Description
RH	Relative Humidity Input
T	Temperature Input
DP	Dew Point Input (internally calculated)
ΔT	ΔT Input (internally calculated)
Fault sens	Sensor break condition signalled by the diagnostic routines

5-3-4 Relay output alarm destination

Each alarm is identified by a specific Modbus variable in which are present both the alarm logical value and the content of the configuration register. In addition, it is possible to address the function to the relay output. All the alarms can be addressed to the relay output in OR mode.

Name	Description
None	No alarm destination
AND Relay	The alarm is connected in AND mode to the other alarms and in OR mode to the relay alarm output
OR Relay	The alarm is connected in OR mode to the other alarms on the relay alarm output

5-3-5 Alarm types

In the table that follows are described the alarm types available:

Name	Description
None	Alarm disabled
Fault-sens	Sensor break alarm
Hi	Input Higher than the Hi alarm threshold
Lo	Input Lower than the Lo alarm threshold
DevHi	Input Higher than a specified value from the reference value
DevLo	Input Lower than a specified value from the reference value
BandOut	Input external to the band defined by the threshold values from the reference value
BandIn	Input internal to the band defined by the threshold values from the reference value
Rate	When the changing rate of the variable connected to the alarm is higher than the specified threshold, the alarm is activated. The threshold is in digit/s
Hi+delay	Input Higher than the Hi alarm threshold for a specified period of time
Lo+delay	Input Lower than the Lo alarm threshold for a specified period of time
DevHi+delay	Input Higher than a specified value from the reference value for a specified period of time
DevLo+delay	Input Lower than a specified value from the reference value for a specified period of time
BandOut+delay	Input external to the band defined by the threshold values from the reference value for a specified period of time

Name	Description
BandIn+ delay	Input internal to the band defined by the threshold values from the reference value for a specified period of time
Rate+ delay	When the changing rate of the variable connected to the alarm is higher than the specified threshold for a specified period of time, the alarm is activated. The threshold is in digit/s

5-4 Relay Output

Relay output is always present on H5 line, the relay has 1 NO contact for signal loads. The relay is activated by the presence of any alarms set. The contact can be programmed to function in direct (contact closed when energized) or reverse (contact open when energized) mode.

5-5 Real Time Clock (RTC) and Associated Functions

An optional Real Time Clock (associated with the RS485 Serial Communications Adapter) can be installed in the transmitter. The RTC maintains the current date and time and gives the time base for tracing events and data logging. These two special functions can be activated using a Modbus command.

5-5-1 Date and time

The format of date and time data is standard (ref: CEI 870-5-4).

The internal clock can be adjusted only through the Modbus protocol. The information is structured on 4 words as follows:

DATE Register

bit	15							8	7							0
Value	x	x	x	x	M	M	M	M	x	x	x	J	J	J	J	J
	Month								Day							

Note: M = MONTH setting -> value 1... 12;
J = DAY setting -> value 1... 31.

YEAR Register

bit	15							8	7							0
Value	x	x	x	x	M	M	M	M	x	x	x	J	J	J	J	J
	Year															

Note: A = YEAR setting -> value 00... 99

TIME1 Register

bit	15							8	7							0
Value	x	x	x	x	M	M	M	M	x	x	mn	mn	mn	mn	mn	mn
	Ora								Minuti							

Note: H = HOUR setting -> value 0... 23;
mn = MINUTES setting -> value 0... 59.

TIME2 Register

bit	15							8	7							0
Value	ms	ms	ms	ms	ms	ms	ms	ms	ms	ms	ms	ms	ms	ms	ms	ms
	milliseconds															

Note: ms = MILLISECONDS setting -> value 0... 59999.

5-5-2 Tracing Events (DATA EVENT) and Data Logging (DATA LOGGER)

The function is programmable in different operation modes. Every time the system stores the data, it registers all the variable registers, date and time registers plus a register relative to the alarm status which also codes the type of event. It is possible to enable the two storage capabilities separately.

A different functioning mode, called interlaced, activates both the functions with the peculiarity that, when an alarm event happens and during the whole time the alarm is active, the EVENT recording takes place at a frequency different from the one used when no alarms were active. The two times are user programmable via dedicated Modbus registers. The interval between 2 data acquisitions can be set from a minimum of 1 minute to a maximum of 59 minutes.

Data are stored in EEPROM and are not erasable by the user. The circular buffer can store 1024 records and, when full, new data are written in place of older ones.

Operation These functions, specific of this high-end model, can be set, separately and independently, through the Modbus in different modes (register **851**).

- 0** No functions active (default);
- 1** Data EVENT running;
- 2** Data EVENT and data LOGGER independently running;
- 3** Data EVENT and data LOGGER running in interlaced mode.
- 4** Normally the data logger acquires data at the sampling time written in register **430**; when an event occurs (as an alarm), the data logger starts acquiring at the sampling time written in register **431** (normally shorter than the one in register **430**);

Register **432** sets the data Event and data Logger status:

- 0** Functions stopped (default);
- 1** Data acquisition enabled (data Event and data Logger running).

Data format Registered data have always the same format, independently from the function that requires the data. Each record is composed by 7 registers:

Record composition

Registers	Data format
Event type	(note)
Data_RH	RH value
Data_T	T value
Data_DP	DP value
Data_date	See "DATE register" at page 18
Data_year	See "YEAR register" at page 18
Data_time	See "TIME1 register" at page 19

The Event type register directly qualifies the type of stored record. If the value is 0 the record is a data LOGGER record. All bit indications, are valid only if the record is a data EVENT record.

- bit 0... bit 3 Show the alarm type set in ALn-type (t) correspondent to the alarm event occurred;
- bit 4... bit 7 Not used (0 default);
- bit 8... bit 12 Show the number of the activated alarm (AL1... AL5);
- bit 13 Not used (0 default);
- bit 14 Shows if the event is an alarm activation (status changes from OFF to ON) or an alarm end (status changes from ON to OFF): 0 = alarm start/1 = alarm end;
- bit 15 Shows the type of the stored: 0 = LOGGER/1 = EVENT.

EVENT_type register

bit	15						8	7							0
Value	RT	AL	0	AL5	AL4	AL3	AL2	AL1	0	0	0	t	t	t	t
	Alarm_status			Alarm_ALn					ALn-type						

Note: ALx-type (t) = Alarm type set in

- Alarm-ALn (AL1... AL5) = bit 1... bit 5 identify the occurred alarm (those set to 1);
- Alarm-status (AL) = 0 alarm event END; 1 alarm event START;
- Alarm-status (RT) = 0 LOGGER record; 1 EVENT record.

Data are physically registered in EEPROM and are not user erasable. The buffer memory can store 1024 records, is circular (when full, new data overwrite the oldest registered).

Access to stored data

To access the database an index register and up to **56** reading registers must be used. The index register (register **2000**) points the first reading record, considering that *index 0* corresponds to the last stored record (i.e. the most recent). The read registers are those at addresses **2001... 2056**. Accessing all the **56** reading registers allow the user to read **8 complete data records**.

In any case (a single register or a multiple consecutive registers reading) the reading procedure must be preceded by the write index register process.

A particular case can be found when the reading request starts at address **2001**. In this case, at the end of the data transfer, the index register is automatically incremented of the amount of transferred registers. This procedure allows to perform continuous multiple reading through the reading address without writing the index register at the end of each reading.

In order to guarantee the correct reading sequence, the number of acquired registers must be a multiple of the registers contained in a record; this means that is recommended to make a complete reading of each record, otherwise the index register does not count the not-completed record reading so the incomplete record will be read again at the beginning (first element) of the subsequent reading cycle.

5-6 Commands

The available Commands/Functions using the Modbus protocol are:

- Reset the min/MAX variable values;
- Alarm acknowledge;
- Sensor check;
- Event tracer - Data logger Start/Stop command;
- Sensor calibration;
- Sensor substitution.

The commands can be submitted only through the serial communications port using the Modbus protocol.

5-7 Calibration commands



Caution

Transmitters are factory calibrated and no further calibrations are required even after replacing the Humi-chip sensor. If the user should have the necessity to make a fine calibration, the alignment can be made on 1 or 2 points and minimizes measurement errors in real working conditions. This type of calibration does not modify the internal calibration of the sensor.

The calibration and the sensor change functions can also be run by the user and

are protected by a public password. To access the procedure the user must use the register **306** for sensor calibration (to calibrate both Humidity and Temperature) and register **307** to write the sensor substitution data.

5-7-1 Humi-Chip sensor calibration

The calibration procedure must be done through the specific Modbus commands or using “Humidity explorer” software.

There are two different modes to calibrate the sensor; both can be accessed and enabled by the user through a specific command. To access the calibration registers the user must insert the public password writing the value **0x1234** at register **1101**.

The sensor calibration can be done using the 1 or 2 point methods. The reference points are chosen by the user, who must insert the exact calibration values. More far are the two points more accurate will be the variable measurement.

For these operations 4 different registers are reserved to calibrate the Humi-chip sensor, 2 to calibrate the humidity and 2 to calibrate the temperature measurement. The user can reset the calibration procedure using a specific command.

Humidity and Temperature Calibration Method through Modbus Commands

The command register of the calibration procedure is register **306**.

The example that follows describes the 2 point humidity calibration procedure. To calibrate with only one point, the user can omit points **4**, **5** and **6** of the list (writing the register of humidity Hi point data). This method functions like the offset.

It is possible to calibrate the humidity measurement (registers **905** and **906**) and/or Temperature (registers **908** and **909**).

2. The sensor must be in stable environmental conditions according with the first point to be calibrated (**Low**).
3. Write in register **306** the code of calibration Low: **0x2210 (8720)**.
4. Write in register **905** the humidity reference value; the new Low Calibration value has been acquired.
5. Change the environmental conditions to those of the second point (**High**) to be calibrated. To obtain a valid sensor calibration the conditions of the sensor must be stable.
6. Write in register **306** the code of calibration High: **0x2220 (8736)**.
7. Write in register **906** the humidity reference value; the new High Calibration value has been acquired.
8. Write in register **306** the code **0x2250 (8784)** to specify that the new calibration values are to be accepted and the transmitter returns to the normal operation mode.

Calibration value	Operation	Command for register 306
Humidity low	Calibration Humidity reference low (1 st point)	0x2210
Humidity high	Calibration Humidity reference high (2 nd point)	0x2220
Temperature low	Calibration Temperature reference low (1 st point)	0x2230
Temperature high	Calibration Temperature reference (2 nd point)	0x2240
--	Calibration end - store calibration data	0x2250
--	Reset Humidity sensor calibration	0x2300
--	Reset Temperature sensor calibration	0x2400
--	Reset the calibrations and the offsets (RH and T) and returns to the initial condition with a system reset	0x2500

To reset a calibration procedure and return back to the default conditions, the user must write the correct reset command to register **306**.

5-7-2 Sensor replacement

The sensor substitution procedure is not a real calibration process, but is the way to write in the transmitter the date of the sensor replacement.

The Humi-chip characteristics ensure a good measure long term stability (long term stability <0.5% per year) only if the sensor is used in its best working conditions. When the Humi-Chip is mounted in environments with high rates of pollution or conditions near to the sensor limits, permanent drifts can be generated in the sensor performance and the Humi-Chip module must be replaced.

For this scope in the transmitter are present some registers in which the user can store the information about sensor installation date and time. Also these registers are protected by a public password that must be inserted prior to modifying these registers. Every time the sensor is replaced the date and time registers are to be modified as follows:

- Write registers **901**, **902** and **903** with the correct data;
- Write in register **307** the access code **0x4432**;
- The new date and time information are stored.

The correct date and time format is described at paragraph “5-7 - Calibration commands” at page 18.

Chapter 6

The Modbus Protocol

6-1 Communication Lines

H5 line transmitters can be equipped with an optional RS485 serial communications line which can exchange data using the Modbus Protocol. This serial line is used to configure and manage the instrument.

When the RS485 line is not present, it is always possible to configure the transmitter using the internal RS232 line that communicates with the same Modbus protocol.


6-2 Modbus Functions

In the transmitter the following Modbus Functions has been implemented:

- 01 Read Coil Status;
- 02 Read Input Status;
- Read Holding Registers;
- Read Input Registers;
- Force Single Coil;
- Preset Single register;
- Read Status;
- Diagnostic Registers;
- Force Multiple Coils;
- Preset Multiple Registers.

This implementation of the Modbus protocol considers functions 01 and 02 identical as functions 03 and 04. Due to this type of use, the memory area organization is divided in two parts:

- DISCRETE DATA (bit area);
- REGISTERS DATA (word area).



Data are divided in types and assigned to the address ranges that follow:

Data type	Address Range	Sub-field	Data sub-type
Discrete data (area bit)	1... 400	1... 100	Physical digital I/O
		101... 200	Digital I/O extension
		201... 300	Alarms
		301... 400	Status variables
Registers (Area word)	1... 1200	1... 120	Field process I/O data
		121... 200	Device Id/Info area
		201... 300	Field process I/O extension
		301... 400	Non retentive device Mngmt
		401... 800	Retentive device Mngmt
		801... 1000	Configuration data
		1001... 1050	Diagnostics
		1101... 1200	Reserved registers

Writing and Reading limits:

Coils writing in only one message	max. 128
Coils reading in only one message	max. 160
Registers writing in only one message	max. 16
Registers reading in only one message	max. 125

6-3 Common Registers and Diagnostics

6-3-1 MODBUS Exception Responses

The response codes are:

Code	Name	Meaning
01	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server (or slave)
02	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the server (or slave).
03	ILLEGAL DATA VALUE	A value contained in the query data field is not an allowable value for server (or slave)
07	NEGATIVE ACKNOWLEDGE - NACK	The server (or slave) is in the wrong state to process a request of this type or an attempt to write to a read only address has been made.

Note: Code 07 has not been provided by Modbus.org Protocol. Use it for Ascon Technology products compatibility only.

6-3-2 Status register

Accessed by the Function Code 07 - Read Exception Status

Reads 8 output of Exception Status.

Bit	Name	Meaning
1	AL1-Status	Alarm status AL1 (0 = Normal operation; 1 = Alarm status)
2	AL2-Status	Alarm status AL2 (0 = Normal operation; 1 = Alarm status)
3	AL3-Status	Alarm status AL3 (0 = Normal operation; 1 = Alarm status)
4	AL4-Status	Alarm status AL4 (0 = Normal operation; 1 = Alarm status)
5	AL5-Status	Alarm status AL5 (0 = Normal operation; 1 = Alarm status)
6	BitCmd-Ack	Alarm Ack status (Acknowledge status /Alarm reset)
7	OP3 status	OP3 Relay output status (0 = Contact open; 1 = Contact closed)
8	Fault sensor	Sensor break alarm

6-3-3 Diagnostics

Accessed by Function Code 08 - Diagnostics.

The only supported sub code is 0 (0000h) – Return Query Data.

The answer message is identical to the whole request message.

6-4 Discrete data (input and coils)

Registers in this area can be accessed as single bits. The access can be done with function codes **01**; **02**; **05**; **15**. Codes **01** and **02** have identical functionality.

Alarms:

Coil	Name	Meaning	Access
201	AL1-Status	Alarm status AL1 (0 = Normal operation; 1 = Alarm)	R
202	AL2-Status	Alarm status AL2 (0 = Normal operation; 1 = Alarm)	R
203	AL3-Status	Alarm status AL3 (0 = Normal operation; 1 = Alarm)	R
204	AL4-Status	Alarm status AL4 (0 = Normal operation; 1 = Alarm)	R
205	AL5-Status	Alarm status AL5 (0 = Normal operation; 1 = Alarm)	R
206	Fault-sensor	Sensor break alarm	R

Status variable:

Coil	Name	Meaning	Access
301	BitCmd_Res	Min/Max Reset	W
302	BitCmd_Ack	Alarm Acknowledge (note)	R/W
303	BitCmd_tst	Check sensor	W
...
308	OP3-Status	OP3 Relay output status (0 = Contact open; 1 = Contact closed)	R

Note: Writing the variable Alarm Ack can be performed the alarm acknowledge. When reading the variable the response is 0.

6-5 Data registers

The area REGISTER DATA addresses integer registers of 16 bit (word).

6-5-1 Variables and Parameters

All the input variables RH, T, DP and ΔT , are represented with 1 decimal digit.

Measure inputs:

Register	Name	Meaning	Access
1	RT	RH Value (0... 100.0%) – Relative Humidity reached	R
2	T	T Value (-40... +123.8°C) – Temperature measure reached	R
3	DP	DP Value (-40... +123.8°C) – Dew Point value reached	R
4	ΔT	ΔT Value (-40... +123.8°C) – ΔT calculated as T - TDP reached	R
5	RH_MAX	RH Max Value – Max. Relative Humidity value reached	R
6	RH_min	RH Min Value – Min. Relative Humidity value reached	R
7	T_MAX	T Max Value – Max. Temperature value reached	R
8	T_min	T Min Value – Min. Temperature value reached	R
9	DP_MAX	DP Max Value – Max. Dew Point value reached	R

Register	Name	Meaning	Access
10	DP_min	DP Min Value – Min. Dew Point value reached	R
11	DT_MAX	ΔT Max Value – Max. Temperature difference reached	R
12	DTmin	ΔT Min Value – Min. Temperature difference reached	R

Reading the value associated to AO1 and AO2 analogue outputs (the value is connected to the variable present in the configuration registers and represent its content):

Register	Name	Meaning		Access
13	OP1	Analogue OP1 Out Value – Current analogue output value	Opt.	R
14	OP2	Analogue OP2 Out Value – Current analogue output value	Opt.	R

Atmospheric pressure value used for the calculations (the variable is not used, for this reason is Read only):

Register	Name	Meaning	Access
15	Pressure	Pressure compensation 1013.25 hPa (NOT USED)	R

Global Alarm Status

Register	Name	Meaning	Access
16	Global_al	Global Alarm Status	R

Alarms indication (note)

bit	15							8	7						0	
Default	0	0	0	0	0	0	0	0	0	0	FAULT	AL5	AL4	AL3	LA2	AL1

Note: The bit status 1 means that the correspondent alarm or output is active.

Node address

Register	Name	Meaning	Access
41	NodeAddr	Serial Comm. Address (replied at reg. 801)(note)	R/W

Protocol

Register	Name	Meaning	Access
41	NodeAddr	Serial Comm. Address (replied at reg. 801) (note)	R/W

Baudrate

Register	Name	Meaning	Access
109	Baudrate	Baud Rate selection register Register (replied at reg. 802) (note)	R/W

Note: Registers **41**, **108** e **109**, are present for conformity to historical Ascon Tecnologia settings. Registers **41** and **109** are replied at registers **801** and **802**. Writing to and reading at one of the registers (**41** and **801**, **109** and **802**) produce the same effect on both the registers.

6-5-2 Identity Registers

Fixed product identification registers (for details on these registers see “Chapter 8 - Configuration” at page 31).

Register	Name	Meaning	Access
121	ManuConf	Factory Code (600)	R
122	ProdCode-1	Product Code (H5)	R
123	ProdCode-2	Product Code	R
124	ProdCode-1	Hardware Release	R
125	ProdCode-2	Software Release	R
126	SpecialCode	Reserved (Reserved to special product versions)	R

6-5-3 Command registers

Commands that can be used during the normal transmitter functioning (for details on these registers see “Chapter 8 - Configuration” at page 31).

Register	Name	Meaning	Access
301	Cmd_Res	min/MAX Reset	W
302	Cmd_Ack	Alarm Ack	W
303	Cmd_tst	Sensor test	W

Note: Pulse type commands. Writing 1 in a register the relative command is executed; when exiting the operation the register is automatically reset to zero (0).

Sensor calibration commands

A detailed description is present at paragraph “Chapter 5 - Advanced functions” at page 13.

Register	Name	Meaning	Access
306	Cmd:Calsens	Sensor calibration	W
307	Cmd_SCngsens	Sensor change	W

Registers to access analogue outputs calibration (AO1 and AO2) password protected.

Register	Name	Meaning	Access
399	Module_Cmd	Command to activate the module calibration phases	R/W

System commands

A detailed description is present at “Chapter 7 - Commands” at page 29

Register	Name	Meaning	Access
400	Command	System commands	R/W

6-5-4 Retentive registers

High (HI) and low (LO) output limits.

Register	Name	Meaning	Access
401	AO1_LO	Start of range analogue output 1 (AO1)	R/W
402	AO1_HI	End of range analogue output 1 (AO1)	R/W
403	AO2_LO	Start of range analogue output 2 (AO2)	R/W
404	AO2_HI	End of range analogue output 2 (AO2)	R/W

Alarm setting

Register	Name	Meaning	Access
405	AL1-SP	Alarm_1 Threshold	R/W
406	AL2-SP	Alarm_2 Threshold	R/W
407	AL3-SP	Alarm_3 Threshold	R/W
408	AL4-SP	Alarm_4 Threshold	R/W
409	AL5-SP	Alarm_5 Threshold	R/W
410	AL1-hy	Alarm_1 Hysteresis	R/W
411	AL2-hy	Alarm_2 Hysteresis	R/W
412	AL3-hy	Alarm_3 Hysteresis	R/W
413	AL4-hy	Alarm_4 Hysteresis	R/W
414	AL5-hy	Alarm_5 Hysteresis	R/W
415	AL1-delay	Alarm_1 delay	R/W
416	AL2-delay	Alarm_2 delay	R/W
417	AL3-delay	Alarm_3 delay	R/W
418	AL4-delay	Alarm_4 delay	R/W
419	AL5-delay	Alarm_5 delay	R/W
420	AL1-reference	Alarm_1 reference	R/W
421	AL2-reference	Alarm_2 reference	R/W
422	AL3-reference	Alarm_3 reference	R/W
423	AL4-reference	Alarm_4 reference	R/W
424	AL5-reference	Alarm_5 reference	R/W

Relay output setting

Register	Name	Meaning	Access
425	OP1-action	Alarm relay output setting (0 = normal operation/1 = reverse operation)	R/W

Real Time Clock (RTC) setting

Register	Name	Meaning	Access
426	RTC_time1	RTC time (hour and minute)	R/W
427	RTC_time2	RTC time (millisecond)	R/W
428	RTC_date	RTC date (month and day)	R/W
429	RTC_year	RTC year	R/W
430	RTC_sample1	RTC data logger sampling time (in minutes max. 59)	R/W
431	RTC_sample2	Data logger sampling time during EVENT tracing (max. 59)	R/W
432	Cmd_memo_eventlog	EVENT and LOGGER Acquisition Start/Stop [5-5-2 - Tracing Events (DATA EVENT) and Data Logging (DATA LOGGER)]	R/W

6-5-5 Configuration registers

The Configuration Registers Address range from 801... 1000. Read “*Chapter 8 - Configuration*” for details about Configuration Registers management. All Configuration registers are protected by “*Public password*” 0x1234 (4660) which is to be written at address 1101, the registers are recordered only if are followed by the command 400 0x5354 (21337).

Register	Name	Meaning	Access
801	NodeAddr	Serial Comm. Address (replied at register 41)	R/W
802	BaudRate	Baud Rate setting (replied at register 109)	R/W
803	Unit	Engineering Units °C/°F	R/W
804	Decimal	Decimal digits	R
805	OP2-Type	Analogue OP2 out type	R/W
806	OP2-Source	Analogue OP2 signal source	R/W
807	OP3-Type	Analogue OP3 out type	R/W
808	OP3-Source	Analogue OP3 signal source	R/W
809	AL1-type	AL1 alarm type	R/W
810	AL2-type	AL2 alarm type	R/W
811	AL3-type	AL3 alarm type	R/W
812	AL4-type	AL4 alarm type	R/W
813	AL5-type	AL5 alarm type	R/W
814	AL1-reset	AL1 Reset Latching/Blocking	R/W
815	AL2-reset	AL2 Reset Latching/Blocking	R/W
816	AL3-reset	AL3 Reset Latching/Blocking	R/W
817	AL4-reset	AL4 Reset Latching/Blocking	R/W
818	AL5-reset	AL5 Reset Latching/Blocking	R/W
819	AL1-source	AL1 Source	R/W
820	AL2-source	AL2 Source	R/W
821	AL3-source	AL3 Source	R/W
822	AL4-source	AL4 Source	R/W
823	AL5-source	AL5 Source	R/W
824	AL1-out	AL1 Destination Out	R/W
825	AL2-out	AL2 Destination Out	R/W
826	AL3-out	AL3 Destination Out	R/W
827	AL4-out	AL4 Destination Out	R/W
828	AL5-out	AL5 Destination Out	R/W
...
851	RTC_func_eventlog	EVENT and LOGGER setting	R/W
...
901	SensorCal_date	Date - sensor calibration (month, day)(note)	R/W
902	SensorCal_year	Date - sensor calibration (year)(note)	R/W
903	SensorCal_Time	Date - sensor calibration (hour, minute)(note)	R/W
904	Sensor_humi_adj	Humidity Offset	R/W
905	SensorCal_value_humi_low	Humidity LO calibration setting (note)	R/W
906	SensorCal_value_humi_high	Humidity HI calibration setting (note)	R/W
907	Sensor_temp_adj	Temperature Offset	R/W
908	SensorCal_value_temp_low	Temperature LO calibration setting (note)	R/W
909	SensorCal_value_temp_high	Temperature HI calibration setting (note)	R/W
...
1000	CoolReset	Cool Reset (value = 298)	W

Note: For a detailed description of these registers see paragraph “5-7 - Calibration”.

6-5-6 Diagnostic Registers

Registers reserved for diagnostic purposes.

Analogue output diagnostic

Register	Name	Meaning	Access
1001	diag_reg0	Analogue Outputs calibration diagnostic	R

Value	Values displayed
0	No error
1	Error values (CRC fault)

Analogue Output diagnostic

Register	Name	Meaning	Access
1003	diag_reg2	Analogue Output diagnostic	R

Value	Values displayed
0	Normal mode
1	Diagnostic mode. OP1 and OP2 output value

6-5-7 DATA EVENT and DATA LOGGER registers

Index to access a specific address of the EVENT/LOGGER log records.

Register	Name	Meaning	Access
2000	event_log_index	Index of the log reading element	W

Registers of the EVENT/LOGGER records

Register	Name	Meaning	Access
2001	event_log[0]	Event_type[i]	R
2002	event_log[1]	Data_RH[i]	R
2003	event_log[2]	Data_T[i]	R
2004	event_log[3]	Data_DP [i]	R
2005	event_log[4]	Data_date[i]	R
2006	event_log[5]	Data_year[i]	R
2007	event_log[6]	Data_time[i]	R
2008	event_log[7]	Event_type[i+1]	R
...	-	-	-
2049	event_log[48]	Data_time[i+6]	R
2050	event_log[49]	Event_type[i+7]	R
2051	event_log[50]	Data_RH[i+7]	R
2052	event_log[51]	Data_T[i+7]	R
2053	event_log[52]	Data_DP [i+7]	R
2054	event_log[53]	Data_date[i+7]	R
2055	event_log[54]	Data_year[i+7]	R
2056	event_log[55]	Data_time[i+7]	R

Note: i = Index of the log reading element (value of the event_log_index).

Chapter 7

Commands

Commands are divided in two parts:

- Program commands;
- System and special commands.

7-1 Program commands

Program commands are present as coils and as registers. They can be found at addresses **301... 308**.

7-1-1 Cmd_Res

Register	Name	Meaning	Access
301	Cmd_Res	Min/Max Reset	W

Pulse type command. Writing 1 all minimum and maximum registers are reset (registers 5... 12). Exiting the command the register is automatically reset.

7-1-2 Cmd_Ack

Register	Name	Meaning	Access
302	Cmd_Ack	Alarm Ack	W

Pulse type command. Writing 1 all registers of alarms configured as latching are reset (registers 5... 12). Exiting the command the register is automatically reset.

7-1-3 Cmd_tst

Register	Name	Meaning	Access
303	Cmd_tst	Sensor test	W

Pulse type command. Writing 1 the system tests the sensor. Exiting the command the register is automatically reset.

7-1-4 Cmd_calsens

Register	Name	Meaning	Access
306	Cmd_Calsen	Humi-chip sensor calibration	W

Carefully read paragraph “5-7 - Calibration commands” at page 18 for details.

7-1-5 Cmd_cnsgsens

Register	Name	Meaning	Access
307	Cmd_Cnsgsens	Humi-chip sensor calibration	W

Carefully read paragraph “5-7 - Calibration commands” at page 18 for details.

7-2 System Commands

System commands are present only as registers. Calibration commands, channel selection and activate the calibration status use registers **398** and **399** that are password protected. Operating System commands use only the register at address **400**.

7-2-1 Calibration Commands

Register	Name	Meaning	Access
399	Module_Cmd	Activate calibration status	R/W

Carefully read paragraph “5-7 - Calibration commands” 18 for details.

7-2-2 Operating System Commands

Register	Name	Meaning	Access
400	Command	Operating system command	R/W

Available commands:

Value	Command
21332 (0x5354)	STORE parameters in EEPROM
21075 (0x5253)	RESTORE parameters in EEPROM
21076 (0x5254)	Transmitter RESET

7-2-3 Cmd_memo_eventlog

Registro	Nome	Note	Accesso
432	Cmd_memo_eventlog	Operating system command	R/W

The command is stored in EEPROM. Available settings:

Value	Operation
0	Stop – acquisition stopped (default)
1	Start – acquisition running

Chapter 8

Configuration

This chapter describes the configuration registers and setting procedures. The transmitter configuration can be done only through the serial communications port using Modbus protocol. In this way the user can set the serial communications parameters, the output and the alarm functioning modes.

All Configuration registers are protected by “Public password” **0x1234 (4660)** which is to be written at address **1101**. To definitively store the new configuration data, the user must, before exiting the configuration phase, send the **STORE** command (**21332**) to address **400**.

To exit the configuration and inhibit further access to these addresses, the user must, before exiting the configuration phase, write a **0** (zero) to address **1101**.

8-1 Registers

8-1-1 Modbus Register Setting

Register	Name	Meaning	Access
41	NodeAddr	Serial Comm. Address (replied at reg. 801)	R/W
801	NodeAddr	Serial Comm. Address (replied at reg. 41)	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	1	1	1	1	0	1	1	1

Setting Values for NodeAddr register.

Value	Address
0 not valid	0 reserved
1	1
...	...
F7h (default)	247
F8... FFh not valid	248... 256 reserved

Note: Register 41 is present for conformity to historical Ascon Tecnologic settings. Register **41** is replied at register **801**. Writing to and reading at one of the registers (**41** and **801**) has the same effect on both the registers.

8-1-2 Baud Rate Setting

Register	Name	Meaning	Access
109	Baudrate	Baud Rate selection register (replied at reg. 802) (note)	R/W
802	BaudRate	Baud Rate selection register (replied at reg. 109) (note)	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0

Setting Values for Baudrate register.

Value	Baud Rate
0	300
1	1200
2	2400
3	4800
4 (default)	9600
5	19200

Note: Register **109** is present for conformity to historical Ascon settings. Register **109** is replied at register **802**. Writing to and reading at one of the registers (**109** and **802**) has the same effect on both the registers.

8-1-3 Temperature Engineering Units

Register	Name	Meaning	Access
803	Unit	Temperature engineering units °C/°F	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Setting Values for Unit register:

Value	Baud Rate
0 (default)	°C
1	°F

Note: All unused bits are set to 0.

8-1-4 Decimal digits

Register	Name	Meaning	Access
804	Decimal	Number of decimal digits to be considered for conversion	R

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1

Note: The register is READ ONLY. It is set to 1 that means 1 decimal digit.

8-1-5 Analogue Output Type

Register	Name	Meaning	Access
805	OP1-Type	AO1 Analogue Output Type	R/W
807	OP2-Type	AO2 Analogue Output Type	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Setting Values for **OPx-Type** register:

Value	OPx-Type
0 (default)	4... 20 mA
1	0... 20 mA
2	0... 10 V
3	0... 5 V
4	0... 1 V

Note: All unused bits are set to 0.

8-1-6 Input Source for Analogue Outputs

Register	Name	Meaning	Access
806	OP1-Source	Input Source for Analogue Output AO1	R/W
808	OP2-Source	Input Source for Analogue Output AO2	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Setting Values for **OPx-Source** registers:

Value	OPx-Source
0 (default)	RH
1	T
2	DP
3	ΔT

Note: All unused bits are set to 0.

8-1-7 Alarm Type Setting

Register	Name	Meaning	Access
809	AL1-Type	Alarm AL1 - Alarm type	R/W
810	AL2-Type	Alarm AL2 - Alarm type	R/W
811	AL3-Type	Alarm AL3 - Alarm type	R/W
812	AL4-Type	Alarm AL4 - Alarm type	R/W
813	AL5-Type	Alarm AL5 - Alarm type	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Setting values for ALx-Type registers (see "Alarm types" for details):

Value	Alx-Type
0 (default)	None
1	Fault-sens (break sensor)
2	Hi
3	Lo
4	DevHi
5	DevLo
6	BandOut
7	BandIn
8	Rate
9	Hi+delay
10	Lo+delay
11	DevHi+delay
12	DevLo+delay
13	BandOut+delay
14	BandIn+delay
15	Rate+delay

Note: All unused bits are set to 0.

8-1-8 Alarm Reset Type Setting

Register	Name	Meaning	Access
814	AL1-Reset	AL1 reset type Latching/Blocking	R/W
815	AL2-Reset	AL2 reset type Latching/Blocking	R/W
816	AL3-Reset	AL3 reset type Latching/Blocking	R/W
817	AL4-Reset	AL4 reset type Latching/Blocking	R/W
818	AL5-Reset	AL5 reset type Latching/Blocking	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Setting values for **ALx-Reset** register:

Value	ALx-Reset
0 (default)	Auto
1	Latching
2	Auto + Blocking
3	Latching + Blocking

Note: All unused bits are set to 0.

8-1-9 Alarm Source Setting

Register	Name	Meaning	Access
819	AL1-Source	AL1 Alarm source	R/W
820	AL2-Source	AL2 Alarm source	R/W
821	AL3-Source	AL3 Alarm source	R/W
822	AL4-Source	AL4 Alarm source	R/W
823	AL5-Source	AL5 Alarm source	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Setting values for **ALx-Source** registers:

Value	ALx-Source
0 (default)	RH Value
1	T Value
2	DP Value
3	Δ T Value

Note: All unused bits are set to 0.

8-1-10 Alarm Output Setting

Register	Name	Meaning	Access
824	AL1-out	Setting the Alarm output for AL1	R/W
825	AL2-out	Setting the Alarm output for AL2	R/W
826	AL3-out	Setting the Alarm output for AL3	R/W
827	AL5-out	Setting the Alarm output for AL4	R/W
828	AL5-out	Setting the Alarm output for AL5	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Setting values for **ALx-out** registers:

Value	ALx-Out
0 (default)	None
1	OR on relay output OP3
2	AND on relay output OP3

Note: All unused bits are set to 0.

8-1-11 Register of analogue outputs value on sensor error

Register	Name	Meaning	Access
829	error_sens_value	Analogue output value in case of sensor error	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

The value that is to be inserted is the percentage of the output signal and is written in decimal units. The entered value can be between **0... 1010** (101%). A number greater than **1010**, is automatically entered as **1010** with no error message.

8-1-12 EVENT Logging Registers

Register	Name	Meaning	Access
825	RTC_func_eventlog	EVENT and LOGGER functioning mode	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Setting values for **RTC_func_eventlog** registers:

Value	RTC_func_eventlog
0 (default)	None
1	Data EVENT function active
2	Data event and Data logger active independently
3	EVENT and LOGGER active and interlaced. In this functioning mode, the data logger normally acquires at the rate indicated at register 430 ; when an event happens the data logger acquires at a different rate (as indicated at register 431 that normally is shorter than the one at register 430).
4	Data LOGGER function active

Note: All unused bits are set to 0.

8-1-13 Humidity and Temperature Offset Registers

The registers contain the offset for the Relative Humidity and Temperature measurements. The value has a decimal digit that must be added or subtracted to the measurement.

Register	Name	Meaning	Access
904	Sensor_humi_adj	Relative Humidity Offset	R/W
907	Sensor_temp_adj	Temperature offset	R/W

Start-up setting:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Note: The default value can be forced to the transmitter also in case of calibration reset writing code **0x2500** at address **306**.

8-1-14 Reset Register

Register	Name	Meaning	Access
1000	CoolReset	Cool Reset (value = 298)	W

Chapter 9

Configuration Tools

9-1 System requirements

To function properly Humidity Explorer requires one of the following configurations:

- Pentium II, 1GHz;
- 512 MB RAM;
- 20 MB of free space on disk;
- CD-ROM graphic card with a minimum resolution of 1024*768;
- Windows 2003, Windows XP SP1 or Windows Vista 32bit.


9-2 Installing and executing the configuration software

9-2-1 Installing the program

Insert the CD-ROM: the installation page should open automatically if autorun is active; if not, access your CD-ROM and double click the “Install.exe” icon file.

Entering the configuration software

After loading the software, enter the program by clicking: “Start”; “Programs”; “Humidity Explorer” and then selecting “H5” in the “file” “new” pull down menu.



Caution

The default parameters are:

- Serial port: COM1;
- Communications sped: 9600 baud;
- Protocol: ModBus;
- Address: 247.

To connect the transmitter make sure that the communication parameters are correctly set.

9-3 File menu and Parameter setting


9-3-1 Saving the transmitter data




WARNING!

Inside the new transmitters are recorded some data (e.g.: **release no.**, **configuration**, etc.) used by the program to configure itself. Upload these data from the transmitter and backup them in a file for a possible future use.

9-3-2 To save the transmitter settings in a file

Select the tab “*Upload Cnf*”. Click on the button  under the heading “*Parameters and Configuration*” to copy the transmitter settings into the Configuration software.



Completed the Upload procedure, store the settings as a file, these data can be saved as a permanent record and used to configure another transmitter. Click on “*File*” and then “*Save*”. A “*Save as*” window will open, with a highlighted file name shown as *.h5 (for H5 transmitters). Over-type the * with the filename required, leaving the .h5 as the file extension, as in normal Windows® practice. Click “*OK*”. In any case the program sets the suffix automatically.




While saving the binary format of the configuration, the program writes, in the same directory, a text file in which are recorded the configuration parameters. Example:

Address	Description	Value
1	RH Value (Read Only)	340
2	T. Value (Read Only)	262
3	DP Value (Read Only)	91
4	Δ T Value (Read Only)	170
5	RH Max Value (Read Only)	902
6	RH Min Value (Read Only)	0
...


9-3-3 Parameters setting


Click on the tabs “*Configuration*”, “*Parameters*”, “*Access*” and select the required settings. To modify the configuration parameters, please use the pull down menus as shown.



For a detailed description of all parameters see “*Chapters 5, 6 and 7*”.


9-3-4 To send the parameters setting into the transmitter (Download conf.)

When the parameters have been correctly configured on the Personal Computer, to send the data to the H5 transmitter. Serlect the tab “*Download Cnf*”, then click on the button  under the heading “*Parameters and Configuration*” to send the settings to the instrument.



9-3-5 To store the configuration as a file (Save)

To store the transmitter settings as a file, which can be saved as a permanent record and used at a later date to configure another transmitter, click on “File” and then “Save”, a “Save as” window will open, with a highlighted file name shown as *.h5 (for H5 transmitters). Over-type the * with the desired filename, leaving the .h5 as the file extension, as in normal Windows® practice. Click “OK”. In any case the program sets the suffix automatically.




While saving the binary format of the configuration, the program writes, in the same directory, a text file in which are recorded the configuration parameters. Example:

Address	Description	Value
1	RH Value (Read Only)	340
2	T. Value (Read Only)	262
3	DP Value (Read Only)	91
4	Δ T Value (Read Only)	170
5	RH Max Value (Read Only)	902
6	RH Min Value (Read Only)	0
...


9-3-6 To recall a previously stored file

To recall a previously stored file, click on “File” and then “Open”, or click on the open icon at the top of the window. In both cases, the open window will appear, which will list all previously stored file names with the file extension appropriate to the controller as listed above. Click on the file required and then click “OK”. When required, the file can be downloaded to a new transmitter as described above.



9-3-7 Setting the Options


The Options tab mask allows the user to check type and number of the options installed in the transmitter and to set them as desired. For the options installed this mask can be used as an alternative of the Configuration screen and its tabs. After having read the Options installed in the transmitter using the “*Check Options*” button, the user can enable or disable each option by clicking on the desired check mark window.



9-3-8 Printing the configuration

To print the present configuration of the instrument: select “*file*” from the main window, select “*Print Conf*” from the menu.

The following will be printed: all the configuration tab sheets; all the parameter tab sheets; the Access page. The printing will be equal to the “*print screen*”.





9-4 Communications menu

9-4-1 Communications parameters setting

Control the header of the program window, all the communications parameters are listed there. Correct the wrong values by clicking the “Comms” pull down menu and making the correct selection in the various sub-menus.

Click on “Comms” and “Port” and check that the port number corresponds to the one being used on the computer. Click on the correct port number if there is a check mark in the wrong setting.

Click on “Comms” and “Baudrate” and check that it is set to 9600 for instruments **without** the RS485 communications option. For instruments **with** RS485, control that the setting in the configuration software is the same as in the instrument. Correct the value if there is a check mark in the wrong position.



Caution

The default parameters are:


- Serial port: COM1;
- Communications speed: 9600 baud;
- Protocol: ModBus;
- Address: 247.

To connect the transmitter make sure that the communication parameters are correctly set.

Click on “Comms” and “Protocol” and check that it is set to “Mbus”. Correct it if the mark is on the wrong setting.

9-5 Trend Menu

The trend menu is available on the main page of the configuration software. The trend menu allows to display on a graphic page the time trend of the process variable of the connected transmitter. The time scale is available as “Number of acquisitions”.



Functions of the buttons:

- **Close:** The program returns to the main page of the configurator;
- **Zoom out:** Shows the entire acquisition time (from the beginning to the button stroke moment);
- **Reset:** Restarts the acquisition procedure;
- **Stop:** Stops the acquisition;
- **Print:** Prints the displayed trend page;
- **MAX:** High end setpoint limit;
- **MIN:** Low end setpoint limit;
- **Enable auto min./max.** (automaticalluy limits the range):
If enabled, the range of the Trend is automatically updated;;
- **Pause:** Time (in milliseconds) elapsed between two transmitter queries;
- **Note:** Field available for user's notes, can only be used in combination with printing.

9-6 Menu “Commands”

9-6-1 Min./Max. Reset

This menu item allows to reset the registers containing the min./max. values stored in the transmitter, the corresponding register is automatically reset.

9-6-2 Alarm Ack

This menu item allows to reset all alarms recorded and configured as latching. The register is automatically reset.

9-6-3 Store configuration on EEPROM

This menu item allows the storage the custom configuration set by the user in the non volatile memory (EEPROM) of the transmitter.

9-6-4 Device Reset

This menu item allows for the transmitter reset.

9-6-5 Restore Default configuration

This menu item allows to reload the original configuration in the transmitter.




Caution

All data in the transmitter will be lost (parameters set by the user, stored data, etc.).


9-7 Database

Data from “*Data event*” and “*Data Logger*” functions are stored in the transmitter memory and can be retrieved by the Humidity Controller program in order to made them available to the user.

From the **H5** menu run the command “*Read the Data-Base*”.




Humidity Controller will display the database screen that contains all the messages stored by the system.



Using this screen the user can:

- Read the Event/Logger data;
- Start/stop the database reading;
- Set how the Event/Logger functions must work.

Please refer to “Chapter 10 - “Data event” and “Data logger”” at page 49.



Pressing the “Export to Excel” button, the user can save in a spreadsheet the data in the database. Will be presented to the user mask “Save As” and if the option “Create a file for Event and files for Logger” is disabled the system will create a single file with the name set by the user containing all data in the database. If the option “Create a file for Event and files for Logger” is active, the system will create two files where the file-name specified by the user will be integrated with “_EVENTS” and “Logger” depending the contents of the file.

From this screen the user can also reset the database and display the trend graph of the data stored in the system. “Save BMP” allows the user to convert the graph of the trend in **BMP** graphic format and save it.



9-8 Sensor Calibration



Caution

The Humi-chip sensor requires no calibration as is supplied pre-calibrated. If the user has the need to fine-calibrate in presence of well known conditions, the sensor can be calibrated on one or two points, without altering the original sensor data calibration.

9-8-1 “Humi-Chip” sensor calibration procedure

The calibration procedure must be done using the “Humidity Explorer” software or through Modbus commands (please refer to paragraph “5-7 - Calibration commands” at page 18 for details).

The sensor calibration can be performed on one or two points. The reference points are chosen by the user who must enter the exact values of the calibra-


tion being performed. The farther away the 2 points are, the more accurate the calibration will be.

Through a specific command, the calibration procedure can be reset at any time.


Calibrate Humidity/Temperature Reading

1 Point Calibration

1. From the menu select the 1 point calibration mode;



2. From the menu select the 1 point calibration mode;




3. Confirm the value just inserted. In case of error, the system will report any malfunction using numerical codes in the "Error Code" box.
4. Press the key "Accept Calibration" in order to force the system accepting the calibration just done.

In the calibration screen the following buttons can be found:


<i>Confirm first point:</i>	Notifies the system the insertion of the first reference value;
<i>Read RH (T):</i>	Reads the Humidity or Temperature value;
<i>Stop:</i>	Stops the Relative Humidity or Temperature reading;
<i>Reset Errors:</i>	Cleans the codes of all the stored error messages;
<i>New Calibration:</i>	Starts a new calibration session;
<i>Accept Calibration:</i>	Notifies the system that the user wants to store the calibration data;
<i>Cancel Calibration:</i>	Cancel the calibration process;
<i>Restore Calibration:</i>	Restore a previously saved calibration procedure;
<i>Close:</i>	Close the window and end the calibration process.

2 Points Calibration

1. From the menu select the 2 points calibration mode;



2. Lead the process (and the sensor) to a stable condition of humidity or temperature for the desired Low Range; enter the umidity (or temperature) value in the “First point - Humidity Low” (o “First point - Temperature Low”) calibration screen box. Confirming the value just inserted using the “Confirm first point” button. At this point the program displays the “Second point - Humidity High” (or “Second point - Temperature High”) screen, change the process functioning conditions in order to reach the second calibration point, wait until the readings are stable. Insert the High Range value in the “Second point - Humidity High” (o “Second point - Temperature High”) box and confirm it pressing the “Confirm second point” button.



3. In case of error, the system will report any malfunction using numerical codes in the “Error Code” box.
4. Press the key “Accept Calibration” in order to force the system accepting the calibration just done.

In the calibration screen the following buttons can be found:

<i>Confirm first point:</i>	Notifies to the system the insertion of the Low Range value (First point - Humidity (or Temperature) low);
<i>Confirm second point:</i>	Notifies to the system the insertion of the High Range value (Second point - Humidity (o Temperature) high);
<i>Read RH (T):</i>	Reads the Humidity or Temperature value;
<i>Stop:</i>	Stops the Relative Humidity or Temperature reading;
<i>Reset Errors:</i>	Cleans the codes of all the stored error messages;
<i>New Calibration:</i>	Starts a new calibration session;
<i>Accept Calibration:</i>	Notifies to the system that the user wants to store the calibration data;
<i>Cancel Clibration:</i>	Cancels the calibration process;
<i>Restore Calibration:</i>	Restores a previously saved calibration procedure;
<i>Close:</i>	Closes the window and end the calibration process.

Chapter 10

“Data event” and “Data logger”

10-1 Functioning mode

The data store function is present only using the **H5** transmitter, it user programmable with the **851** register. The **851** register allows:

- [0] No action enabled (default);
- [1] EVENT active;
- [2] EVENT and LOGGER independently active;
- [3] EVENT and LOGGER active and interlaced.

In this mode, during normal operations, the Data Logger acquires at the sampling time stored in register **430**. When an event occurs, the Data Logger starts acquiring using the sampling time at register **431**, normally shorter than the other one;

- [4] Data LOGGER active.

When Data LOGGER is active independently from Data EVENT, it uses the sampling time stored at register **430**. The sampling time is expressed in minutes and can be set in the range 1... 59 min. Register **432** determines the operation status: if **0** the function is disabled, if is written at **1** the function is active.

10-2 Data format

Registered data have always the same format, independently from the function that requires the data. Each record is composed by 7 registers:

Registers	Data format
Event type	(Note)
Data_RH	RH value
Data_T	T value
Data_DP	DP value
Data_date	Paragraph 3.5.3 (reg. DATE)
Data_year	Paragraph 3.5.3 (reg. YEAR)
Data_time	Paragraph 3.5.3 (reg. TIME1)

Note: The Event type register directly qualifies the type of stored record. If the value is 0 the record is a data LOGGER record. All bit indications, are valid only if the record is a data EVENT record.

- bits 0... 3: indicate the type of alarm set in Aln-type (t) corresponding to the alarm occurred;
- bits 4... 7: not used (0 default);
- bits 8... 12: indicate which is the alarm occurred (AL1... AL5);
- bit 13: not used (0 default);
- bit 14 indicates if the event is started or is ended:
0 = Alarm start/**1** = Alarm end;
- bit 15 indicates which record type has been recorded:
0 = LOGGER/**1** = EVENT.

The 8 least significant bits indicate the type of alarm; bits 8 to 12 indicate which alarm has occurred; bit 14 indicates whether the indicated event has started or ended; bit 15 indicates the type of record stored (EVENT or LOGGER).

bit	15							8	7							0
Value	RT	AL	0	AL5	AL4	AL3	AL2	AL1	0	0	0	t	t	t	t	t
	Alarm_status			Alarm_ALn					ALn-type							

Where: **Alarm-ALn (AL1... AL5)** = the bit set to 1 shows which alarm has been activated;
Alarm-status (AL) = 0 end of the alarm event; **1** start of the alarm event;
Alarm-status (RT) = 0 LOGGER record; **1** EVENT record.

Data are stored in EEPROM and cannot be erased by the user. The buffer can store 1024 records; when the available space is filled, the transmitter writes over the older data.

10-3 Accessing the stored data

The database can be accessed using an index register and up to **56 reading registers**. The index register (reg. **2000**) indicates which is the first reading record, taking into account that the index 0 corresponds to the last stored record (i.e. the most recent data). The reading registers are at addresses **2001... 2056**. **Accessing all the 56 registers allows to read 8 complete data records.**

Each reading, whether of a single register rather than multiple consecutive registers, must be preceded by the writing of the index register.

A special case is when the read request is executed starting from address **2001**. In this case, at the end of the information transfer, the index register is incremented automatically by the system to just the number of registers transferred. This allows a sequence of multiple readings through the reading registers without having to retype each time the index register. In order to guarantee the correct reading sequence, the number of acquired registers must be a multiple of the registers contained in a record; this means that it is recommended to make the complete reading of each record, otherwise the index register does not count the register that has not been fully read, but will repeat the same register reading as the first element of the subsequent reading cycle.

Chapter 11

Diagnostics

The system has several diagnostic registers. Each of them is able to control or provide any information about system problems. Below is a description of each.

11-1 Analogue output calibration diagnostic values (diag_reg0)

The register returns the error code referred to the calibration values of analog outputs stored in EEPROM. The check is performed controlling the stored CRC code. There are two copies for each stored register to allow the data recovery. If the error code is 1 the stored data are non valid or are not yet initialized.

Register	Name	Meaning	Access
1001	diag_reg0	Analogue Outputs calibration diagnostic values	R

Allowed error codes:

Value	Values displayed
0	No error
1	Error value (CRC fault)

11-2 Analogue Output diagnostic (diag_reg2)

The register is active both in writing and reading. Writing in this register a value different than "0" and equal or less than "1000" activates the diagnostic mode for the two analogue output.

In this diagnostic mode, the system is stopped, the value inserted by the user (0... 1000) is the percentage of the output (0 = 0.0% ... 1000 = 100.0%), it is written in the register and the outputs will be placed at that value. Each output is set with respect to the type of output previously set. Write 0 in the register to return to normal operation mode.

Register	Name	Meaning	Access
1003	diag_reg2	Analogue Output diagnostic	R/W

Valid error codes:

Value	Values displayed
0	Normal mode
1	Diagnostic mode. OP1 and OP2 output value

All the other values are reported as error. Example:

- Output OP1 set in the range 0... 20 mA;
- Output OP2 set in the range 0... 10 V.

If the value **344** is written in register **1003**, the system writes on the display (when present) the analogue output diagnostic status and the two outputs are placed at the **34.4%** of their output range:

- Output OP1 = 6.880 mA (34.4% of 20 mA)
- Output OP2 = 3.44 V (34.4% of 10 V).

11-3 Humi chip sensor calibration diagnostic values (diag_reg3)

This register returns the error code referred to the sensor calibration values. Each bit represents an error function. If a bit value is **1** indicates that an error has occurred for which the calibration must be repeated. Writing in the register resets all the bit.

Register	Name	Meaning	Access
1004	diag_reg3	Humi chip sensor calibration diagnostic values	R/W

bit error definition:

bit	15							8	7							0
Default	0	0	0	0	0	0	0	0	0	0	TO	HO	TH	TL	HH	HL

Where: **HL** Humidity sensor low range calibration value;
HH Humidity sensor high range calibration value;
TL Temperature sensor low range calibration value
TH Temperature sensor high range calibration value;
HO Humidity sensor shift;
TO Temperature sensor shift.

Valid error values:

Value	Values displayed
0	Normal mode
1	Error codes (write 0 to erase the errors)

Appendix A

Modbus Address Map



WARNING!

Inside the manual reference is made to the Modbus registers, while in these pages the Modbus addresses are listed. The relationship between addresses and registers is as follows:

Register = Address + 1

(example: the measured humidity value RH is at address 0, equal to register 1).

A-1 Modbus Address Map

Address	Name	Meaning	Access
0	RH	RH Value (0... 100.0%) – Relative Humidity measure reached	R
1	T	T Value (-40... +123.8°C) – Temperature measure reached	R
2	DP	DP Value (-40... +123.8°C) – Dew Point value reached	R
3	DT	ΔT Value (-40... +123.8°C) – ΔT calculated as T - TDP reached	R
4	RH_MAX	RH max. value – Max. Relative Humidity value reached	R
5	RH_min	RH min. value – Min. Relative Humidity value reached	R
6	T_MAX	T max. value – Max. Temperature value reached	R
7	T_min	T min. value – Min. Temperature value reached	R
8	DP_MAX	DP max. value – Max. Dew Point value reached	R
9	DP_min	DP min. value – Min. Dew Point value reached	R
10	DT_MAX	ΔT max. value – Max. Temperature difference reached	R
11	DTmin	ΔT min. value – Min. Temperature difference reached	R
12	OP1	Analogue OP1 Out Value – Current analogue output value	R
13	OP2	Analogue OP2 Out Value – Current analogue output value	R
14	Pressure	Pressure compensation 1013.25 hPa (not used)	R
15	Global_al	Global Alarm Status	R
...
40	NodeAddr	Serial Comm. Address (replied at reg. 801)(note)	R/W
...
107	Protocol	ModBud/JBus protocol register (fixed to Modbus)(note)	R/W
108	Baudrate	Baud Rate selection register Register (replied at reg. 802) (note)	R/W
...
120	ManuConf	Factory Code (600)	R
121	ProdCode-1	Product Code (H5)	R
122	ProdCode-2	Product Code	R
123	ProdCode-1	Hardware Release	R

Address	Name	Meaning	Access
124	ProdCode-2	Software Release	R
125	SpecialCode	Reserved (Reserved to special product versions)	R
...
300	Cmd_Res	Min./MAX. Reset (2)	W
301	Cmd_Ack	Alarm acknowledge (2)	W
302	Cmd_tst	Sensor test (2)	W
...
305	Cmd:Calsens	Sensor calibration	W
306	Cmd_SCngsens	Sensor change	W
...
398	Module_Cmd	Command to activate the module calibration phases	R/W
399	Command	System commands	R/W
400	OP1_LO	Start of range analogue output 1 (AO1)	R/W
401	OP1_HI	End of range analogue output 1 (AO1)	R/W
402	OP2_LO	Start of range analogue output 2 (AO2)	R/W
403	OP2_HI	End of range analogue output 2 (AO2)	R/W
404	AL1-SP	Alarm_1 Threshold	R/W
405	AL2-SP	Alarm_2 Threshold	R/W
406	AL3-SP	Alarm_3 Threshold	R/W
407	AL4-SP	Alarm_4 Threshold	R/W
408	AL5-SP	Alarm_5 Threshold	R/W
409	AL1-hy	Alarm_1 Hysteresis	R/W
410	AL2-hy	Alarm_2 Hysteresis	R/W
411	AL3-hy	Alarm_3 Hysteresis	R/W
412	AL4-hy	Alarm_4 Hysteresis	R/W
413	AL5-hy	Alarm_5 Hysteresis	R/W
414	AL1-delay	Alarm_1 delay	R/W
415	AL2-delay	Alarm_2 delay	R/W
416	AL3-delay	Alarm_3 delay	R/W
417	AL4-delay	Alarm_4 delay	R/W
418	AL5-delay	Alarm_5 delay	R/W
419	AL1-reference	Alarm_1 reference	R/W
420	AL2-reference	Alarm_2 reference	R/W
421	AL3-reference	Alarm_3 reference	R/W
422	AL4-reference	Alarm_4 reference	R/W
423	AL5-reference	Alarm_5 reference	R/W
424	OP1-action	Alarm relay output setting (0 = normal operation/1 = reverse operation)	R/W
425	RTC_time1	RTC time (hour and minute)	R/W
426	RTC_time2	RTC time (millisecond)	R/W
427	RTC_date	RTC date (month and day)	R/W
428	RTC_year	RTC year	R/W
429	RTC_sample1	RTC data logger sampling time (in minutes max. 59)	R/W
430	RTC_sample2	Data logger sampling time during EVENT tracing (max. 59)	R/W
431	Cmd_memo_eventlog	EVENT and LOGGER Acquisition Start/Stop (see Chapter 5.5.2 for details)	R/W
432	Cmd_cngmenu	Change display mode	R/W
...
800	NodeAddr	Serial Comm. Address (replied at register 41)	R/W
801	BaudRate	Baud Rate setting (replied at register 109)	R/W

Address	Name	Meaning	Access
802	Unit	Engineering Units °C/°F	R/W
803	Decimal	Decimal digits	R
804	OP2-Type	Analogue OP2 out type	R/W
805	OP2-Source	Analogue OP2 signal source	R/W
806	OP3-Type	Analogue OP3 out type	R/W
807	OP3-Source	Analogue OP3 signal source	R/W
808	AL1-type	AL1 alarm type	R/W
809	AL2-type	AL2 alarm type	R/W
810	AL3-type	AL3 alarm type	R/W
811	AL4-type	AL4 alarm type	R/W
812	AL5-type	AL5 alarm type	R/W
813	AL1-reset	AL1 Reset Latching/Blocking	R/W
814	AL2-reset	AL2 Reset Latching/Blocking	R/W
815	AL3-reset	AL3 Reset Latching/Blocking	R/W
816	AL4-reset	AL4 Reset Latching/Blocking	R/W
817	AL5-reset	AL5 Reset Latching/Blocking	R/W
818	AL1-source	AL1 Source	R/W
819	AL2-source	AL2 Source	R/W
820	AL3-source	AL3 Source	R/W
821	AL4-source	AL4 Source	R/W
822	AL5-source	AL5 Source	R/W
823	AL1-out	AL1 Destination Out	R/W
824	AL2-out	AL2 Destination Out	R/W
825	AL3-out	AL3 Destination Out	R/W
826	AL4-out	AL4 Destination Out	R/W
827	AL5-out	AL5 Destination Out	R/W
...
850	RTC_func_eventlog	EVENT and LOGGER setting	R/W
...
900	SensorCal_date	Date - sensor calibration (month, day)	R/W
901	SensorCal_year	Date - sensor calibration (year)	R/W
902	SensorCal_Time	Date - sensor calibration (hour, minute)	R/W
903	Sensor_humi_adj	Humidity Offset	R/W
904	SensorCal_value_humi_low	Humidity LO calibration setting	R/W
905	SensorCal_value_humi_high	Humidity HI calibration setting	R/W
906	Sensor_temp_adj	Temperature Offset	R/W
907	SensorCal_value_temp_low	Temperature LO calibration setting	R/W
908	SensorCal_value_temp_high	Temperature HI calibration setting	R/W
...
999	CoolReset	Cool Reset (value = 298)	W
1000	diag_reg0	Analogue Outputs calibration diagnostic values	R
...
1002	diag_reg2	Analogue Output disgnostic	R
1003	event_log_index	Index of the log reading element	W
...
2000	event_log[0]	Event_type [i]	R

Address	Name	Meaning	Access
2001	event_log[1]	Data_RH [i]	R
2002	event_log[2]	Data_T [i]	R
2003	event_log[3]	Data_DP [i]	R
2004	event_log[4]	Data_date [i]	R
2005	event_log[5]	Data_year [i]	R
2006	event_log[6]	Data_time [i]	R
2007	event_log[7]	Event_type [i+1]	R
...
2048	event_log[48]	Data_time [i+6]	R
2049	event_log[49]	Event_type [i+7]	R
2050	event_log[50]	Data_RH [i+7]	R
2051	event_log[51]	Data_T [i+7]	R
2052	event_log[52]	Data_DP [i+7]	R
2053	event_log[53]	Data_date [i+7]	R
2054	event_log[54]	Data_year [i+7]	R
2055	event_log[55]	Data_time [i+7]	R

- Notes:**
1. Registers 41, 108 and 109 (addresses 40, 107 and 108) are maintained for compliance with Ascon Technologic historical settings. Registers 41 and 109 are replicated at addresses 801 and 802 (addr. 800 and 801) respectively. Writing or reading one or the other of the registers produces the same effect on both.
 2. Impulse type commands. Writing 1 in the register, the indicated command is executed; when exiting the operation, the register value is automatically reset to zero (0).

Appendix B


Characteristics

B-1 Technical characteristics


Characteristics at 25°C environmental temperature		
Relative Humidity (RH)	Range	0.0...100.0% RH
	Resolution	12 bit
	Sampling time	1/s
	Temperature limits	-30... +90°C (figure 1)
	Accuracy (figure 2)	1.8% between 10... 90% RH, non-linearity, hysteresis and repeatability included
	Typical long-term drift	< 0.5 RH% per year
Temperature (T)	Available ranges	-30.0... +70.0°C (-22... 158°F)
		-20.0... +30.0°C (-4... 86°F)
		0.0... +50.0°C (32... 122°F)
		0.0...+100.0°C (32... 212°F)
		Other ranges on request in range -40.0... 128.0°C (-40... 262.4°F)
	Resolution	14 bit
Dew Point (DP)	Available ranges	-30.0... +70.0°C (-22... 158°F)
		0.0...+100.0°C (32... 212°F)
		Other ranges on request in °C or °F selectable using the RS485
	Accuracy (figure 4)	<1°C between 30... 100%RH and
		-20... +90°C (-4... +164°F)
$\Delta T = T - TDP$	Range	0.0... 50.0°C (32... 122°F)
Analogue outputs 1 and 2	Output type	4... 20 mA; 500W max.
		0... 10 V; 20 mA max.
		0... 1 V; 20 mA max.
		0... 20 mA and 0... 5 V can be set through the serial port
Serial communications	Isolation	Galvanic isolation of each output: 500 Vdc/1 min
	Retransmitted measurement	Typically analogue output 1 transmits RH, analogue output 2 transmits T (H5 can transmit also DP or DT)
	Type	Isolated 3 wires RS485, with protocol Modbus RTU Slave
Alarms	Baud Rate	Selectable up to 19200 Baud
	Number	5, combinable with each measurement (RH, T, DP, DT) or Humi-chip failure
	Type	Min./Max., delayed and/or stored
	Output type	1 Relay SPST, max. 1 A at 30 Vdc/1A at 120 Vac, directly activated by each alarm or with AND/OR logic

Characteristics at 25°C environmental temperature		
Process auditing	Recording method	FIFO buffer in non volatile memory (1024 records). Data cannot be altered. Record format: event type, RH, T, DP, ΔT and date/time. 5 recording methods available
	Event logging	When an alarm occurs, the system starts storing the event records at a rate different from the data logging rate
	Data logging	The measured values are cyclically recorded. Recording timing: 1... 59 min
Power supply	18... 27 Vac or 20... 30 Vdc	Power consumption 2W max.
General characteristics	Housing material	Epoxy painted aluminum (RAL 7038) Protection: IP66
	Probe material	PVDF - probe for duct mounting version
	Safety	Compliance to EN 61010-1, double isolation, pollution class 2, installation class II
	Electromagnetic compatibility	Compliance to CE standards EN 50081-2, EN 50082-2
	Environmental temperature housing	-25... +70°C standard
	Electrical connections	Standard: spring terminal strip, AWG28-16 wire
	Dimensions	Consult paragraph "2.2 - Dimensions" for details

Working limits of Humi-Chip module




Temperature Tolerance




Note: The measured reading tolerance is guaranteed through the "Normal" working conditions. A long-time period, at "Limit" conditions may generate a permanent drift up to +2% RH.

Humidity tolerance



Dew Point Calculation Tolerance



Appendix C

Troubleshooting

Appendix D

Warranty

D-1 Warranty and repairs

The instrument is under warranty against manufacturing flaws or faulty material, that are found within 18 months from delivery date. The warranty is limited to repairs or to the replacement of the instrument.

The eventual opening of the housing, the violation of the instrument or the improper use and installation of the product will bring about the immediate withdrawal of the warranty effects.

In the event of a faulty instrument, either within the period of warranty, or further to its expiry, please contact our sales department to obtain authorisation for sending the instrument to our company.

The faulty product must be shipped to Ascon Tecnologic with a detailed description of the faults found, without any fees or charge for Ascon Tecnologic, except in the event of alternative agreements.

