



## ZTT-16 (SEM210) ZTT-17 (SEM210X) USER GUIDE

SMART IN HEAD MOUNTED UNIVERSAL TRANSMITTER  
TWO WIRE (4 to 20) mA OUTPUT



**Important - Please read this document before any installing.**

Every effort has been taken to ensure the accuracy of this document, however we do not accept responsibility for damage, injury, loss or expense resulting from errors and omissions, and we reserve the right of amendment without notice.



### IMPORTANT - CE & SAFETY REQUIREMENTS

Product must be mounted inside a suitable enclosure providing environmental protection to IP65 or greater.

To maintain CE EMC requirements, input wires must be less than 3 metres.

The product contains no serviceable parts, or internal adjustments. No attempt must be made to repair this product. Faulty units must be returned to supplier for repair.

This product must be installed by a qualified person. All electrical wiring must be carried out in accordance with the appropriate regulations for the place of installation.

Before attempting any electrical connection work, please ensure all supplies are switched off.

ABSOLUTE MAXIMUM CONDITIONS (To exceed may cause damage to the unit) :-

Supply Voltage	$\pm 30$ V dc (Protected for over voltage and reverse connection)
Current with over voltage	$\pm 100$ mA
Input Voltage	$\pm 3$ V between any terminals
Ambient	Temperature (-40 to 85) °C Humidity (10 to 95) % RH (Non condensing)

### Conditions for use




The ZTT-16-17 temperature transmitter should be mounted in an enclosure with a minimum IP rating of IP54. The enclosure should be specified to operate in the ambient temperature range of (-40 to 85) °C.

## Maintenance

The ZTT-16-17 apparatus contains no user serviceable adjustable, replaceable parts. No attempt should be made to repair a ZTT-16-17 device, all units must be returned to the manufacturer for repair or replacement. Attempted service or replacement of parts may invalidate the warranty of the ZTT-16-17.

## Mechanical Detail



The ZTT-16-17 is mounted using two holes, on standard 33 mm fixing centres and will fit a DIN standard termination head. The ZTT-16-17 must be installed with adequate protection from moisture and corrosive atmospheres. Refer to conditions for use section of this user guide for information on enclosure IP rating. Care must be taken to ensure the ZTT-16-17 is located to ensure the ambient temperature does not exceed the specified operating temperature. A 6.3 mm hole is provided in the centre of the transmitter for sensor wires. The sensor wires may also be fed on the outside of the transmitter.

## Installation



For ZTT-16-17 specification please refer to product data sheet. Installation is normally performed in the following order. If the ZTT-16-17 has been purchased as part of a probe assembly, steps (1 to 3) will have been completed. The user may wish to reconfigure the transmitter range, in this instance the ZTT-16-17 range can be changed on a completed probe assembly by following step 1.

1. Configuration
2. Mount Transmitter into head
3. Wire Sensor
4. Install Assembly
5. Wire (4 to 20) mA Loop

### 1. Configuration

**Note: - The ZTT-16-17 can be configured whilst connected and powered, but a portable battery powered computer must be used to avoid the effects of ground loops if the (4 to 20) mA loop is grounded. This may damage the ZTT-16-17.**



Use the latest version of USBSpeedLink



Once software is installed remove protection cover from device port, plug in USB Lead to device port and connect PC using USB cable.

In USBSpeedLink software, select Model type from "Field Product - In Head TX" menu. For further information on configuration please open the help menu on the product configuration screen. On completion of configuration remove USB cable and replace protective cover over socket.

Factory default setting Sensor PT100 range (0 to 100) °C,

The main configuration is performed using the USB interface. The following parameters may be configured using the powerful USBSpeed link software tool, which also provide operator diagnostics.

The following functions apply :-

#### SENSOR

Sensor type	mV, Dual mV, ohms, slide wire, thermocouple, dual thermocouple, RTD, dual RTD (2 wire).
Sensor wire	(ohms and rtd ranges only) 2, 3, or 4 wire.
Thermocouple type	Download from USBspeedlink expanding library, common type K,J,T,E,R,S,N,B,U,G,C,D.
Thermocouple CJ	Fixed or Auto.
RTD type	Download from USBspeedlink expanding library, common type PT100, PT1000, PT500, Ni, CU, KTY series.
Sensor(s) Fail	Value on sensor A, (sensor B) fail.
Sensor Pre-set	Override sensor signal with pre-set value, primary function diagnostics.

#### PROCESS

Scaling	Scale sensor signal to PV, options - Off, Two point scaling or (4 to 22) step profile.
Units	Set PV units

#### mA Output

Damping	Profile out damping (0 to 32) seconds.
Range	Range (PV units) For (4 to 20) mA output.
Fix Loop Current	Fix loop current to pre-set value (Note resets on power up) . Primary use Diagnostics.
Set Max mA	Set the maximum output current (20 to 23)mA.
Set min mA	Set minimum output current (3.5 to 4.0) mA.
Trim	Read set and reset (4 and 20) mA Trim values.

#### DIAGNOSTICS

Power ups	Number of power ups from manufacture.
Min Max PV	Minimum and maximum process variable value during operation with reset.
Operating times	From manufacture and calibration. Calibration time is resettable.
Calibration	Store Date, operator and certificate number.
Save Data	Save transducer data to text file.

#### DIAGNOSTCS LOG

Type	150 point non volatile Process Variable log, with power off indication and sensor fail (not time stamped).
Rates	User set log periods seconds 5, 15, 30 minutes 1, 2, 5, 10, 20, 30, or 60.
Backup	Save log to PC in CSV style format (using semi colon delimiter) for easy export to text editor or spreadsheet.


#### PROCESS DATA

Data	Live data for sensor (TV) ,pre-scaling, post scaling (PV), Untrimmed mA output, Actual mA output, % output signal and device ambient temperature (SV) (cold junction).
Diagnostics	Sensor wire error detect (not supported in mV mode), Loop power detect.

## 2. Mount Transmitter into Head

The ZTT-16-17 is mounted using two holes, on standard 33 mm fixing centres and will fit a DIN standard termination head. The ZTT-16-17 must be installed with adequate protection from moisture and corrosive atmospheres. Refer to conditions for use section of this user guide for information on enclosure IP rating. A centre hole is provided in the ZTT-16-17 case, this allows for sensor wire to enter wiring section through the ZTT-16-17 body.

3. Sensor Connection




4. Install assembly

Care must be taken to ensure the ZTT-16-17 is located to ensure the ambient temperature does not exceed the specified operating temperature

5. Wire (4 to 20) mA Loop

Ensure all other aspects of the installation comply with the requirements of this document. The (4 to 20) mA loop is connected as follows:-



Additional Information

- EMC BS EN 61326-1  
(Sensor wires maximum length 3 metres to comply.)
- Enclosure Colour Black